



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	GROMMET A; 17247-240-000;	002
02	ARM, KICK STARTER; 28240-393-770;	001
03	BRKT, KICK STARTER; 28242-393-000;	001
04	BOLT ASSY. (10MM); 28248-371-000;	001
05	RUBBER, KICK STARTER; 28311-329-000;	001
06	BAND; 28334-393-770;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
07	BATTERY (Y50-N18L-A); 31500-463-747AH;	001
08	CABLE; 32601-393-000;	001
09	BOX ASSY., BATTERY; 50320-393-770;	001
10	CUSHION, BATTERY; 50321-393-000;	002
11	BAR; 50322-393-000;	001

12	RUBBER A, BATTERY; 50323-300-010;	002
13	COLLAR, BATTERY BOX; 50324-300-000;	002
14	RUBBER B, BATTERY; 50327-300-000;	001
15	RUBBER A; 50328-371-000;	002
16	STAY, BATTERY; 50332-393-000;	001
17	RUBBER, BATTERY BOX; 83618-323-000;	003
18	BOLT, HEX. (6X12); 92101-06012-0A;	001
18	BOLT, HEX. (6X12); 92101-06012-0A;	001
18	BOLT, HEX. (6X12); 92101-06012-0A;	001
19	BOLT-WASHER (6X25); 93494-06025-07;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
20	NUT, HEX. (6MM); 94001-06200-0S;	002
21	WASHER, PLAIN (6MM); 94101-06800;	001
21	WASHER, PLAIN (6MM); 94101-06800;	001
21	WASHER, PLAIN (6MM); 94101-06800;	001
22	WASHER, SPRING (6MM); 94111-06000;	002
23	PIN, LOCK (14MM); 94251-14000;	002
24	BOLT, FLANGE (6X10); 95701-06010-00;	001
24	BOLT, FLANGE (6X10); 95701-06010-00;	001