



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	AXLE, FR. WHEEL 44301-425-870	001
01	AXLE, FR. WHEEL 44301-425-870	001
01	AXLE, FR. WHEEL 44301-425-870	001
02	COLR, FR. WHEEL SIDE 44311-371-980	001
03	HUB, FR. WHEEL 44601-405-000	001
04	BALANCER (20G) 44606-283-000	AR
04	BALANCER (15G) 44607-283-000	AR
04	BALANCER (10G) 44608-283-000	AR
04	BALANCER, WHEEL (5G) 44609-283-000	AR
05	SPOKE ASSY. A, FR. 44606-371-305	020
06	SPOKE ASSY. B, FR. 44607-371-305	020
07	COLLAR, FR. 44620-300-020	001
08	RETAINER, GEAR BOX 44641-375-000	001
09	COVER 44642-300-020	001
10	RETAINER, FR. 44643-300-000	001
11	RIM, FR. WHEEL 44701-371-003	001

12	TIRE, FR. (3.50H-19) 44711-371-671	001
13	TUBE, TIRE 44712-371-003	001
13	TUBE, TIRE 44712-371-003	001
13	TUBE, TIRE 44712-371-003	001
13	TUBE, TIRE 44712-371-003	001
14	FLAP, TIRE 44713-MR1-671	001
14	FLAP, TIRE (1.85-19) 44713-371-004	001
14	FLAP, TIRE 44713-MR1-671	001
15	BOX ASSY. 44800-300-030	001
16	DISK, FR. BRAKE 45120-392-000	001
17	BOLT (8X102) 90122-300-020	006
18	NUT, AXLE (12MM) 90306-425-870	001
18	NUT, AXLE (12MM) 90306-425-870	001
19	NUT, HEX. (8MM) 90309-357-000	006
20	DUST SEAL (22X36X8) 91252-300-003	001
21	O-RING (58X2) 91302-300-000	001
22	SCREW, OVAL (5X16) 93700-05016-0A	001
23	BEARING (6302UU) 96150-63020-10	002
23	BEARING (6302UU) 96150-63020-10	002