



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	GUIDE, VALVE 12025-300-300	004
02	GUIDE, EX. VALVE 12027-300-330	004
03	RUBBER, INSERT 12620-286-000	002
03	RUBBER, INSERT 12620-286-000	002
04	CYLINDER HEAD 12200-392-000	001
05	CLIP, VALVE GUIDE 12211-250-310	008
06	ORIFICE, OIL CONTROL 12238-300-010	002
07	GASKET, CYL HD 12251-300-306	001
07	GASKET, CYL HD 12251-300-306	001
08	INSULATOR 1, CARB 16211-393-020	001
09	INSULATOR 2, CARB 16212-393-020	001
10	INSULATOR 3, CARB 16213-393-010	001
11	INSULATOR 4, CARB 16214-393-010	001
12	BAND, A/CLNR TUBE 17255-230-000	004
13	BAND, INSULATOR 16223-KS5-000	004
13	BAND, INSULATOR 16223-KS5-000	004
14	BOLT, STUD (6X58) 90055-300-000	004
15	NUT, FLANGE (8MM) 94050-08000	016

15	NUT, FLANGE (8MM) 94050-08000	016
15	NUT, FLANGE (8MM) 94050-08000	016
16	WASHER (14MM) 90485-035-000	016
17	O-RING (5.8X1.9) 91305-323-000	004
17	O-RING (5.6X1.9) 91318-ME5-003	004
18	RUBBER, SEALING 91318-300-013	006
19	BOLT, STUD (8X32) 92900-08032-0E	008
19	BOLT, STUD (8X32) 92900-08032-0E	008
20	SCREW, PAN (4X20) 93500-04020-0A	004
21	SCREW, PAN (4X22) 93500-04022-0A	004
21	SCREW, PAN (4X22) 93500-04022-0A	004
21	NUT, FLANGE (8MM) 94050-08000	016
22	PIN, DOWEL (8X14) 94301-08140	006
23	BOLT, FLANGE (6X35) 95701-06035-00	005
23	BOLT, FLANGE (6X35) 95701-06035-00	005
24	BOLT, FLANGE (6X90) 95701-06090-00	001
24	BOLT, FLANGE (6X90) 95701-06090-00	001
25	SPARK PLUG (D8EA) 98069-58717	004
25	SPARK PLUG (D8EA) 98069-58717	004
25	SPARK PLUG (D8EA) 98069-58717	004
25	SPARK PLUG (D8EA) 98069-58717	004
25	SPARK PLUG (D8EA) 98069-58717	004
25	SPARK PLUG (D8EA) 98069-58717	004