



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	ADJUSTER 40543-392-000	001
01	ADJUSTER 40543-392-000	001
02	SPROCKET (42T) 41201-393-770	001
03	PLATE, SPROCKET SIDE 41211-405-000	001
04	RETAINER, RR. 41231-283-000	001
05	RETAINER, RR. 41231-300-020	001
06	DAMPER, RR. WHEEL 41241-300-050	004
07	AXLE, RR. WHEEL 42301-425-870	001
07	AXLE, RR. WHEEL 42301-425-870	001
08	COLR, RR. WHEEL SIDE 42311-425-870	001
08	COLR, RR. WHEEL SIDE 42311-425-870	001
09	HUB, RR. WHEEL 42601-300-050	001
09	HUB, RR. WHEEL 42601-300-050	001
10	SLEEVE, RR. AXLE 42605-393-000	001
11	SPOKE ASSY. A, RR. 42606-393-700	020
11	SPOKE ASSY. A, RR. 42606-393-700	020
12	SPOKE ASSY. B, RR. 42607-393-700	020
12	SPOKE ASSY. B, RR. 42607-393-700	020
13	FLANGE, FINAL DRIVEN 42610-405-000	001
14	COLLAR, RR. DISTANCE 42620-ME1-405	001

14	COLLAR, RR. DISTANCE 42620-ME1-405	001
15	RIM, RR. WHEEL 42701-371-003	001
16	TIRE (4.50H17) (4PR) 42711-MA4-671	001
16	TIRE (4.50H17) (4PR) 42711-MA4-671	001
16	TIRE (4.50H17) (4PR) 42711-MA4-671	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
17	TUBE, TIRE (5.10-17) 42712-MA0-005	001
18	FLAP, TIRE (17) 42713-371-000	001
19	BALANCER (20G) 44606-283-000	AR
19	BALANCER (15G) 44607-283-000	AR
19	BALANCER (10G) 44608-283-000	AR
19	BALANCER, WHEEL (5G) 44609-283-000	AR
20	BOLT, CHAIN ADJ. 90119-300-000	001
21	BOLT, STUD (12X54) 90128-341-000	004
22	OIL SEAL (34X55X9) 90753-283-000	001
23	O-RING (68X2.6) 91258-300-013	001
24	NUT, HEX. (8MM) 94002-08000-0S	001
25	NUT, HEX. (12MM) 94030-12000	004
26	WASHER A7, TONGUED 94108-17000	002
27	BEARING (6304U) 96140-63040-10	002
28	BEARING (6305U) 96140-63050-10	001