



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	COVER, L. SIDE 11371-393-010	001
02	PLATE, OIL CAUTION 11372-393-000	001
03	GASKET, L. COVER 11396-393-306	001
04	COVER, RR. 11611-393-000	001
06	DIPSTICK, OIL 15650-393-000	001
07	STARTER MOTOR ASSY. 31200-300-030	001
08	BRUSH SET, CARBON 31201-292-158	001
09	SPRING, CARBON BRUSH 31204-292-158	002
10	BOLT, SETTING 31205-286-158	002
11	O-RING (60X1.4) 31206-402-008	001
11	O-RING (60X1.4) 31206-402-008	001
12	WIRE ASSY., OIL 31270-393-000	001
13	COVER, STARTER MOTOR 31280-300-000	001
14	GSKT, START MTR CVR 31282-300-020	001
15	GROM, O/PRESS SW WR 31283-300-000	001
16	SWITCH, OIL PRESSURE 37240-P13-013	001
16	SWITCH, OIL PRESSURE 37240-P13-013	001
17	OIL SEAL (14X26X6) 91251-ZW5-003	002
17	OIL SEAL (14X26X6) 91251-ZW5-003	002
18	OIL SEAL (18X29X7) 91204-286-003	001
18	OIL SEAL (18X29X7) 91204-286-003	001

19	O-RING (24.4X3.1) 91312-MG7-003	001
19	O-RING (24.4X3.1) 91312-MG7-003	001
19	O-RING (24.4X3.1) 91312-MG7-003	001
20	O-RING (23X2) 91354-371-000	001
20	O-RING (23X2) 91354-371-000	001
21	BOLT, HEX. (6X12) 92101-06012-0B	002
21	BOLT, HEX. (6X12) 92101-06012-0B	002
21	BOLT, HEX. (6X12) 92101-06012-0B	002
22	SCREW, PAN (6X35) 93500-06035-0A	001
22	SCREW, PAN (6X35) 93500-06035-0A	001
23	SCREW, PAN (6X45) 93500-06045-0A	004
23	SCREW, PAN (6X45) 93500-06045-0A	004
24	SCREW, PAN (6X50) 93500-06050-0A	001
24	SCREW, PAN (6X50) 93500-06050-0A	001
24	SCREW, PAN (6X50) 93500-06050-0A	001
25	SCREW, PAN (6X100) 93500-06100	003
26	SCREW, PAN (6X120) 93500-06120	002
27	WASHER, PLAIN (6MM) 94101-06200	002
29	BOLT, FLANGE (6X55) 95701-06055-00	002
29	BOLT, FLANGE (6X55) 95701-06055-00	002