



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	CASE, L. SIDE 11361-393-000	001
02	GASKET, L. CRANKCASE 11395-393-306	001
03	PUMP ASSY., OIL 15100-393-000	001
04	PIPE, OIL PASSAGE 15321-393-000	001
05	RUBBER, OIL PASSAGE 15323-393-000	002
06	BOLT, SEALING (8MM) 90024-612-000	001
07	GASKET (8MM) 90471-580-000	001
08	SCREW, PAN (6X60) 93500-06060-0A	003
08	SCREW, PAN (6X60) 93500-06060-0A	003
08	SCREW, PAN (6X60) 93500-06060-0A	003
09	PIN, DOWEL (8X14) 94301-08140	004
10	BOLT, FLANGE (6X55) 95701-06055-00	004
10	BOLT, FLANGE (6X55) 95701-06055-00	004