



| NUMBER | PART NAME-HONDA#                     | QTY NEEDED |
|--------|--------------------------------------|------------|
| 01     | POINTS ASSY.<br>30200-323-154        | 001        |
| 01     | POINTS ASSY.<br>30200-323-154        | 001        |
| 02     | PLATE, POINT BASE<br>30201-300-154   | 001        |
| 02     | PLATE, POINT BASE<br>30201-300-154   | 001        |
| 03     | POINTS (1&4)<br>30203-300-154        | 001        |
| 03     | POINTS (1&4)<br>30203-300-154        | 001        |
| 04     | POINTS (2&3)<br>30204-300-154        | 001        |
| 04     | POINTS (2&3)<br>30204-300-154        | 001        |
| 05     | FELT, OIL<br>30205-300-154           | 001        |
| 05     | FELT, OIL<br>30205-300-154           | 001        |
| 06     | PLATE, POINTS SHIFT<br>30215-300-154 | 001        |
| 06     | PLATE, POINTS SHIFT<br>30215-300-154 | 001        |
| 07     | ADVANCER, SPARK<br>30220-333-004     | 001        |
| 07     | ADVANCER, SPARK<br>30220-333-004     | 001        |

|    |                                      |     |
|----|--------------------------------------|-----|
| 08 | SHAFT<br>30231-300-010               | 001 |
| 09 | WASHER, SPECIAL<br>30233-300-000     | 001 |
| 10 | CONDENSER<br>30250-300-154           | 002 |
| 10 | CONDENSER<br>30250-300-154           | 002 |
| 11 | COVER, POINTS<br>30370-300-020       | 001 |
| 12 | GASKET, POINT COVER<br>30372-300-300 | 001 |
| 13 | O-RING (6X2.3)<br>91301-300-000      | 001 |
| 14 | SCREW, PAN (5X12)<br>93500-05012-0A  | 003 |
| 15 | SCREW, OVAL (6X32)<br>93700-06032-02 | 002 |
| 15 | SCREW, OVAL (6X32)<br>93700-06032-02 | 002 |
| 15 | SCREW, OVAL (6X32)<br>93700-06032-0B | 002 |
| 15 | SCREW, OVAL (6X32)<br>93700-06032-02 | 002 |
| 16 | NUT, FLANGE (6MM)<br>94050-06000     | 001 |
| 17 | WASHER, PLAIN (5MM)<br>94101-05000   | 003 |

[www.hondachopper.com](http://www.hondachopper.com)