



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	COVER, L. RR. 11351-300-060	001
02	RUBBER 11354-300-010	001
03	COVER, CR/CASE TRANS 11360-300-050	001
04	GASKET, TRANS CVR 11395-300-306	001
04	GASKET, TRANS CVR 11395-300-306	001
05	GEAR 28101-300-000	001
06	SHAFT 28106-300-000	001
07	PLATE 28109-300-000	001
08	GEAR, STARTER CLUTCH 28110-300-000	001
09	STARTER MOTOR ASSY. 31200-300-030	001
10	BRUSH SET, CARBON 31201-292-158	001
11	SPRING, CARBON BRUSH 31204-292-158	002
12	BOLT, SETTING 31205-286-158	002
13	O-RING (60X1.4) 31206-402-008	001
13	O-RING (60X1.4) 31206-402-008	001

14	WIRE ASSY. 31270-300-154	001
15	COVER, STARTER MOTOR 31280-300-000	001
16	GSKT, START MTR CVR 31282-300-020	001
17	GROM, O/PRESS SW WR 31283-300-000	001
18	SWITCH, OIL PRESSURE 37240-P13-013	001
18	SWITCH, OIL PRESSURE 37240-P13-013	001
18	SWITCH, OIL PRESSURE 37240-P13-013	001
19	OIL SEAL (14X28X7) 91206-286-013	001
19	OIL SEAL (14X28X7) 91206-286-013	001
20	OIL SEAL (25X33X4) 91215-300-003	001
21	O-RING (24.4X3.1) 91312-MG7-003	001
21	O-RING (24.4X3.1) 91312-MG7-003	001
21	O-RING (24.4X3.1) 91312-MG7-003	001
22	BOLT, HEX. (6X12) 92101-06012-0B	002
22	BOLT, HEX. (6X12) 92101-06012-0B	002
23	SCREW, PAN (6X32) 93500-06032-0A	002
23	SCREW, PAN (6X32) 93500-06032-0A	002
24	SCREW, PAN (6X35) 93500-06035-0A	002
24	SCREW, PAN (6X35) 93500-06035-0A	002
25	SCREW, PAN (6X40) 93500-06040-0A	003
25	SCREW, PAN (6X40) 93500-06040-0A	003
26	SCREW, PAN (6X50) 93500-06050-0A	002
26	SCREW, PAN (6X50) 93500-06050-0A	002
27	SCREW, PAN (6X55) 93500-06055-0A	002
27	SCREW, PAN (6X55) 93500-06055-0A	002
28	WASHER, PLAIN (6MM) 94101-06200	002
29	PIN, DOWEL (8X14) 94301-08140	002
30	BOLT, FLANGE (6X56) 95700-06056-00	002