



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	REGULATOR ASSY. 31400-300-035	001
02	RUBBER 31403-323-000	002
02	RUBBER 31403-323-000	002
03	RECTIFIER ASSY. 31700-333-008	001
03	RECTIFIER ASSY. 31700-333-008	001
04	CABLE 32401-392-000	001
05	COVER 32412-MJ0-000	001
06	COVER B 32413-300-010	001
07	SW, STARTER MAGNETIC 35850-371-670	001
08	STAY 35851-392-000	001
08	STAY 35851-392-000	001
09	SUB-WIRE, MAGNETIC 35858-392-000	001
10	BOX ASSY., FUSE 38200-377-305	001
10	BOX ASSY., FUSE 38200-377-305	001
11	RELAY, TURN SIGNAL 38301-KJ6-743	001

11	RELAY, TURN SIGNAL 38301-KJ6-743	001
11	RELAY, TURN SIGNAL 38301-KJ6-743	001
11	RELAY, TURN SIGNAL 38301-KJ6-743	001
13	SUSPENSION 38306-092-670	001
15	BASE, ELECTRIC 50330-392-000	001
16	COLLAR 84706-286-000	002
17	NUT 90145-634-670	001
18	WASHER (18MM) 90581-831-650	002
18	WASHER (18MM) 90581-831-650	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
19	BOLT, HEX. (6X16) 92101-06016-0A	002
20	BOLT, HEX. (6X20) 92101-06020-0A	002
20	BOLT, HEX. (6X20) 92101-06020-0A	002
21	NUT, HEX. (8MM) 94001-08000-0S	001
22	WASHER, PLAIN (6MM) 94101-06800	002
22	WASHER, PLAIN (6MM) 94101-06800	002
22	WASHER, PLAIN (6MM) 94101-06800	002
23	WASHER, SPRING (8MM) 94111-08000	001
24	BOLT, FLANGE (6X12) 95701-06012-00	002
24	BOLT, FLANGE (6X12) 95701-06012-00	002
25	FUSE B (7A) 98200-20700	003
26	FUSE B (15A) 98200-21500	002