



| NUMBER | PART NAME-HONDA# | QTY NEEDED |
|--------|---------------------------------------|------------|
| 01 | RING (66.5MM) 13491-300-000 | 001 |
| 02 | RING B 13496-300-000 | 001 |
| 03 | TENSIONER 13620-300-010 | 001 |
| 04 | SPROCKET 23110-392-000 | 001 |
| 05 | CHAIN, PRIMARY (68L) 23131-300-315 | 002 |
| 05 | CHAIN, PRIMARY (68L) 23131-300-315 | 002 |
| 06 | GEAR (50T) 23511-392-000 | 001 |
| 07 | SHAFT, FINAL DRIVEN 23521-392-000 | 001 |
| 08 | SPROCKET (17T) 23801-300-010 | 001 |
| 09 | PLATE 23811-292-000 | 001 |
| 10 | GEAR, KICK STARTER 28210-300-000 | 001 |
| 11 | SPINDLE 28250-300-020 | 001 |
| 12 | FLANGE, KICK STARTER 28271-393-000 | 001 |
| 12 | FLANGE, KICK STARTER 28271-393-000 | 001 |
| 13 | PAWL, KICK STARTER 28252-300-020 | 001 |
| 14 | SPRING 28253-300-000 | 001 |
| 15 | PIN, KICK STOPPER 28254-300-000 | 001 |
| 16 | PIN (4X37) 28255-300-000 | 001 |
| 17 | PIN (6X35) 28256-300-000 | 001 |
| 18 | SPRING 28261-300-010 | 001 |

| | | |
|----|-------------------------------------|-----|
| 19 | BEARING (6008) 91004-300-000 | 001 |
| 20 | BEARING (6205) 96100-62050-00 | 001 |
| 20 | BEARING (6205) 96100-62050-00 | 001 |
| 20 | BEARING (6205) 96100-62050-00 | 001 |
| 20 | BEARING (6205) 96100-62050-10 | 001 |
| 21 | BEARING (5206) 91012-MG7-003 | 001 |
| 21 | BEARING (5206) 91012-MG7-003 | 001 |
| 22 | BEARING (25X32X20) 91010-300-008 | 002 |
| 23 | OIL SEAL (25X62X7) 91205-300-005 | 001 |
| 24 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 24 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 24 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |
| 25 | BOLT, HEX. (6X16) 92101-06016-0A | 001 |