



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	COVER, L. RR. 11351-410-010	001
02	COVER, CRANKCASE 11360-410-010	001
03	GASKET, TRANS CVR 11395-300-306	001
03	GASKET, TRANS CVR 11395-300-306	001
04	GEAR 28101-300-000	001
05	SHAFT 28106-300-000	001
06	PLATE 28109-300-000	001
07	GEAR, STARTER CLUTCH 28110-300-000	001
08	STARTER MOTOR ASSY. 31200-300-030	001
09	BRUSH SET, CARBON 31201-292-158	001
10	SPRING, CARBON BRUSH 31204-292-158	002
11	BOLT, SETTING 31205-286-158	002
12	O-RING (60X1.4) 31206-402-008	001
12	O-RING (60X1.4) 31206-402-008	001
13	WIRE ASSY. 31270-300-005	001

13	WIRE ASSY. 31270-300-154	001
14	COVER, STARTER MOTOR 31280-300-000	001
15	GSKT, START MTR CVR 31282-300-020	001
16	GROM, O/PRESS SW WR 31283-300-000	001
17	SWITCH, OIL PRESSURE 37240-P13-013	001
17	SWITCH, OIL PRESSURE 37240-P13-013	001
18	OIL SEAL (14X28X7) 91206-286-013	001
18	OIL SEAL (14X28X7) 91206-286-013	001
19	OIL SEAL (25X33X4) 91215-300-003	001
20	O-RING (24.4X3.1) 91312-MG7-003	001
20	O-RING (24.4X3.1) 91312-MG7-003	001
20	O-RING (24.4X3.1) 91312-MG7-003	001
21	BOLT, HEX. (6X12) 92101-06012-0B	002
21	BOLT, HEX. (6X12) 92101-06012-0B	002
22	SCREW, PAN (6X32) 93500-06032-0A	002
22	SCREW, PAN (6X32) 93500-06032-0A	002
23	SCREW, PAN (6X35) 93500-06035-0A	002
23	SCREW, PAN (6X35) 93500-06035-0A	002
24	SCREW, PAN (6X40) 93500-06040-0A	003
24	SCREW, PAN (6X40) 93500-06040-0A	003
25	SCREW, PAN (6X50) 93500-06050-0A	002
25	SCREW, PAN (6X50) 93500-06050-0A	002
26	SCREW, PAN (6X55) 93500-06055-0A	004
26	SCREW, PAN (6X55) 93500-06055-0A	004
27	WASHER, PLAIN (6MM) 94101-06200	002
28	PIN, DOWEL (8X14) 94301-08140	002
29	BOLT, FLANGE (6X55) 95701-06055-00	002
29	BOLT, FLANGE (6X55) 95701-06055-00	002