



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	BAND A 30151-300-000	001
02	BAND B 30152-300-000	001
03	COIL ASSY., IGNITION 30500-300-013	001
04	COIL, R. IGNITION 30501-300-003	001
05	COIL, L. IGNITION 30502-300-003	001
06	BRKT, IGNITION COIL 30511-300-000	002
07	WIRE HARNESS 32100-300-050	001
09	BAND B1, WIRE 32161-404-000	004
09	BAND B1, WIRE 32161-404-000	004
09	BAND B1, WIRE 32161-404-000	004
10	BAND B2, WIRE 95014-62200	003
10	BAND B2, WIRE 95014-62200	003
10	BAND B2, WIRE 95014-62200	003
11	TUBE, WIRE 33720-300-000	001
12	SWITCH, IGNITION 35010-315-017	001
12	SWITCH, IGNITION 35010-315-017	001
14	SWITCH, RR. STOP 35350-KJ9-405	001
14	SWITCH, RR. STOP 35350-KJ9-405	001
14	SWITCH, RR. STOP 35350-KJ9-405	001
15	SPRING, STOP SWITCH 35357-300-000	001
16	HORN ASSY. 38100-300-023	001
21	BRACKET *NH1* 50375-300-000B	001
22	WASHER 50376-300-000	001
23	COLLAR 50377-300-000	001
24	CLAMP, TACH CBL 50462-323-010	001
24	CLAMP, TACH CBL 50462-323-010	001
24	CLAMP, TACH CBL 50462-323-010	001
25	BOLT, HEX. (6X16) 92101-06016-0A	002
25	BOLT, HEX. (6X16) 92101-06016-0A	002

25	BOLT, HEX. (6X16) 92101-06016-0A	002
25	BOLT, HEX. (6X16) 92101-06016-0A	002
25	BOLT, HEX. (6X16) 92101-06016-0A	002
25	BOLT, HEX. (6X16) 92101-06016-0A	002
26	BOLT, HEX. (6X25) 92101-06025-0A	002
26	BOLT, HEX. (6X25) 92101-06025-0A	002
27	BOLT, HEX. (6X32) 92101-06032-0A	001
27	BOLT, HEX. (6X32) 92101-06032-0A	001
27	BOLT, HEX. (6X32) 92101-06032-0A	001
28	BOLT, HEX. (8X40) 92101-08040-0A	001
28	BOLT, HEX. (8X40) 92101-08040-0A	001
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
29	NUT, HEX. (6MM) 94001-06200-0S	002
30	WASHER, PLAIN (6MM) 94101-06800	002
30	WASHER, PLAIN (6MM) 94101-06800	002
30	WASHER, PLAIN (6MM) 94101-06800	002
31	WASHER, PLAIN (8MM) 94101-08000	001
32	WASHER, SPRING (6MM) 94111-06000	004