



| NUMBER | PART NAME-HONDA# | QTY NEEDED |
|--------|---------------------------------------|------------|
| 01 | PETCOCK ASSY. 16950-300-020 | 001 |
| 02 | CUP, FUEL STRAINER 16952-268-000 | 001 |
| 03 | LEVER, VALVE 16953-268-020 | 001 |
| 04 | GSKT, PETCOCK VALVE 16955-268-020 | 001 |
| 05 | SCREEN 16957-268-010 | 001 |
| 06 | GASKET 16958-268-010 | 001 |
| 07 | SPRING 16960-268-010 | 001 |
| 08 | PLATE 16961-268-010 | 001 |
| 09 | GASKET, PETCOCK BODY 16997-273-006 | 001 |
| 10 | TANK, FUEL *PB2C* 17050-300-040AZ | 001 |
| 10 | TANK, FUEL *R4C* 17050-300-040CM | 001 |
| 10 | TANK, FUEL *Y2C* 17050-300-040CQ | 001 |
| 10 | TANK, FUEL *YR2C* 17050-300-040EE | 001 |
| 10 | TANK, FUEL *G21M* 17050-300-040EF | 001 |
| 10 | TANK, FUEL *PB9M* 17050-300-040EG | 001 |
| 10 | TANK, FUEL *PB2C* 17050-300-040AZ | 001 |
| 10 | TANK, FUEL *R4C* 17050-300-040CM | 001 |
| 10 | TANK, FUEL *Y2C* 17050-300-040CQ | 001 |
| 10 | TANK, FUEL *YR2C* 17050-300-040EE | 001 |
| 10 | TANK, FUEL *G21M* 17050-300-040EF | 001 |
| 10 | TANK, FUEL *PB9M* 17050-300-040EG | 001 |
| 10 | TANK, FUEL *PB2C* 17050-300-040AZ | 001 |
| 10 | TANK, FUEL *R4C* 17050-300-040CM | 001 |
| 10 | TANK, FUEL *Y2C* 17050-300-040CQ | 001 |
| 10 | TANK, FUEL *YR2C* 17050-300-040EE | 001 |
| 10 | TANK, FUEL *G21M* 17050-300-040EF | 001 |
| 10 | TANK, FUEL *PB9M* 17050-300-040EG | 001 |
| 11 | CAP, FUEL TANK 17510-323-310 | 001 |
| 11 | CAP, FUEL TANK 17510-323-310 | 001 |

| | | |
|----|---------------------------------------|-----|
| 11 | CAP, FUEL TANK 17510-323-310 | 001 |
| 15 | LATCH ASSY. 17550-377-315 | 001 |
| 16 | WASHER 17520-300-300 | 001 |
| 17 | MLDG, R. FUEL TANK 17052-300-000 | 001 |
| 18 | MLDG, R. FUEL TANK 17052-300-000 | 001 |
| 19 | WASHER 17523-300-000 | 001 |
| 20 | SEPARATOR A, FUEL 17524-300-000 | 001 |
| 21 | GASKET 17525-300-000 | 001 |
| 22 | SPRING, SEAT 17526-300-000 | 001 |
| 22 | LATCH ASSY. 17550-377-315 | 001 |
| 23 | RUB, FR. FUEL TANK 17611-283-010 | 002 |
| 24 | RUB, RR. FUEL TANK 17613-292-000 | 001 |
| 25 | GASKET, PETCOCK 17993-250-000 | 002 |
| 26 | EMBLEM, R. FUEL TANK 87121-300-030 | 001 |
| 27 | EMBLEM, R. FUEL TANK 87121-300-030 | 001 |
| 27 | EMBLEM, R. FUEL TANK 87121-300-030 | 001 |
| 28 | NUT, EMBLEM CLAMP 87311-634-600 | 004 |
| 28 | NUT, EMBLEM CLAMP 87311-634-600 | 004 |
| 29 | LABEL *NH0* 87560-323-670A | 001 |
| 29 | LABEL *NH1* 87560-323-670ZA | 001 |
| 29 | LABEL *NH1* 87560-323-670ZA | 001 |
| 30 | SCREW 90167-300-000 | 001 |
| 31 | SCREW, PAN (6X28) 93500-06028-0A | 002 |
| 31 | SCREW, PAN (6X28) 93500-06028-0A | 002 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |

| | | |
|----|---|-----|
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | TUBE (5.5X350) 95001-55000-40 | 001 |
| 32 | BULK HOSE (5.5X8000) 95001-55008-60M | 001 |
| 33 | BULK HOSE (5.5X8000) 95001-55008-60M | 001 |
| 34 | CLIP, TUBE (B10) 95002-02100 | 004 |
| 34 | CLIP, TUBE (C9) 95002-50000 | 004 |