



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	POINTS ASSY. 30200-300-154	001
01	POINTS ASSY. 30200-300-154	001
02	PLATE, POINT BASE 30201-300-154	001
02	PLATE, POINT BASE 30201-300-154	001

02	PLATE, POINT BASE 30201-300-154	001
03	POINTS (1&4) 30203-300-154	001
03	POINTS (1&4) 30203-300-154	001
04	POINTS (2&3) 30204-300-154	001
04	POINTS (2&3) 30204-300-154	001
05	FELT, OIL 30205-300-154	001
05	FELT, OIL 30205-300-154	001
06	PLATE, POINTS SHIFT 30215-300-154	001
06	PLATE, POINTS SHIFT 30215-300-154	001
07	ADVANCER, SPARK 30220-300-154	001
07	ADVANCER, SPARK 30220-300-154	001
08	SHAFT 30231-300-010	001
09	WASHER, SPECIAL 30233-300-000	001
10	CONDENSER 30250-300-154	002
10	CONDENSER 30250-300-154	002
11	GROM, PRIMARY WIRE 30254-300-300	001
12	COVER, POINTS 30370-300-020	001
13	GASKET, POINT COVER 30372-300-300	001
14	O-RING (6X2.3) 91301-300-000	001
15	SCREW, PAN (5X12) 93500-05012-0A	003
16	SCREW, OVAL (6X32) 93700-06032-02	002
16	SCREW, OVAL (6X32) 93700-06032-0B	002
17	NUT, HEX. (6MM) 94002-06000-0S	001
17	NUT, HEX. (6MM) 94002-06000-0S	001
18	WASHER, PLAIN (5MM) 94101-05000	003
19	WASHER, PLAIN (6MM) 94101-06800	001
19	WASHER, PLAIN (6MM) 94101-06800	001
19	WASHER, PLAIN (6MM) 94101-06800	001