



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	REGULATOR ASSY. 31400-300-035	001
02	RUBBER 31403-323-000	002
02	RUBBER 31403-323-000	002
03	BATTERY ASSY. 31500-425-672AH	001
03	BATTERY ASSY. 31500-425-672AH	001
03	BATTERY ASSY. 31500-425-672AH	001
03	BATTERY ASSY. 31500-425-672AH	001
04	RECTIFIER ASSY. 31700-333-008	001
04	RECTIFIER ASSY. 31700-333-008	001
05	SAFETY UNIT 31800-341-701	001
06	BOX ASSY., FUSE 32110-341-702	001
07	COVER, FUSE BOX 32117-341-702	001
08	FUSE, GROMMET 32118-341-702	001
09	CABLE 32401-300-010	001
10	COVER 32412-MJ0-000	001
11	COVER B 32413-300-010	001
12	CABLE 32601-MG9-000	001
12	CABLE 32601-MG9-000	001
12	CABLE 32601-MG9-000	001
13	SW, STARTER MAGNETIC 35850-306-670	001
13	SW, STARTER MAGNETIC 35850-371-670	001
14	STAY 35851-392-000	001
14	STAY 35851-392-000	001
15	RELAY, TURN SIGNAL 38301-KJ6-743	001
15	RELAY, TURN SIGNAL 38301-KJ6-743	001
15	RELAY, TURN SIGNAL 38301-KJ6-743	001
15	RELAY, TURN SIGNAL 38301-KJ6-743	001
16	SUSPENSION 38306-292-670	001
17	BAND F, BATTERY 95012-17001	001

17	BAND F, BATTERY 95012-17001	001
18	RUBBER A, BATTERY 50323-300-010	004
19	COLLAR, BATTERY BOX 50324-300-000	004
20	BOX, BATTERY 50325-341-700	001
22	RUBBER B, BATTERY 50327-300-000	004
23	RUBBER C, BATTERY 50329-300-010	001
24	PLATE, ELECTRIC BASE 50330-341-000	001
25	COLLAR 84706-286-000	002
26	WASHER, PLAIN (6MM) 94103-06800	004
26	WASHER, PLAIN (6MM) 94103-06800	004
27	WASHER (18MM) 90581-831-650	002
27	WASHER (18MM) 90581-831-650	002
28	BOLT, HEX. (5X14) 92101-05014-0A	002
28	BOLT, HEX. (5X14) 92101-05014-0A	002
29	BOLT, HEX. (6X12) 92101-06012-0A	002
29	BOLT, HEX. (6X12) 92101-06012-0A	002
29	BOLT, HEX. (6X12) 92101-06012-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
30	BOLT, HEX. (6X16) 92101-06016-0A	002
31	BOLT, HEX. (6X20) 92101-06020-0A	002
31	BOLT, HEX. (6X20) 92101-06020-0A	002
32	BOLT, HEX. (6X25) 92101-06025-0A	004
32	BOLT, HEX. (6X25) 92101-06025-0A	004
33	NUT, HEX. (6MM) 94001-06200-0S	001
33	NUT, HEX. (6MM) 94001-06200-0S	001

33	NUT, HEX. (6MM) 94001-06200-0S	001
33	NUT, HEX. (6MM) 94001-06200-0S	001
33	NUT, HEX. (6MM) 94001-06200-0S	001
33	NUT, HEX. (6MM) 94001-06200-0S	001
33	NUT, HEX. (6MM) 94001-06200-0S	001
34	NUT, HEX. (8MM) 94001-08000-0S	001
35	WASHER, PLAIN (5MM) 94101-05000	002
36	WASHER, PLAIN (6MM) 94101-06800	004
36	WASHER, PLAIN (6MM) 94101-06800	004
36	WASHER, PLAIN (6MM) 94101-06800	004
37	WASHER, SPRING (6MM) 94111-06000	001
38	WASHER, SPRING (8MM) 94111-08000	001
39	FUSE A (5A) 98200-10500	002
40	FUSE (7A) 98200-10700	002
41	FUSE (15A) 98200-11500	002

www.hondachopper.com