



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	GEAR, KICK STARTER 28210-300-000	001
02	JOINT, KICK STARTER 28241-300-010	001
03	SPINDLE 28250-300-020	001
04	FLANGE, KICK STARTER 28271-393-000	001
04	FLANGE, KICK STARTER 28271-393-000	001

05	PAWL, KICK STARTER 28252-300-020	001
06	SPRING 28253-300-000	001
07	PIN, KICK STOPPER 28254-300-000	001
08	PIN (4X37) 28255-300-000	001
09	PIN (6X35) 28256-300-000	001
10	SPRING 28261-300-010	001
11	SPRING, KICK STARTER 28292-250-010	001
12	CLIP 28293-250-000	001
13	ARM, KICK STARTER 28300-300-000	001
14	RUBBER, KICK STARTER 28311-329-000	001
15	PIN 28321-300-000	001
16	SPRING 28333-300-000	001
17	BOLT, HEX. (8X28) 92101-08028-0A	001
17	BOLT, HEX. (8X28) 92101-08028-0A	001
18	BALL (#8) (1/4) 96211-08000	001

www.hondachopper.com