



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	CRANKSHAFT 13000-300-050	001
02	ROD D, CONNECTING 13204-300-000	004
02	ROD D, CONNECTING 13204-300-000	004
02	ROD D, CONNECTING 13204-300-000	004
02	ROD D, CONNECTING 13204-300-000	004
02	ROD F, CONNECTING 13206-300-000	004
02	ROD F, CONNECTING 13206-300-000	004
02	ROD H, CONNECTING 13208-300-000	004
02	ROD H, CONNECTING 13208-300-000	004
02	ROD H, CONNECTING 13208-300-000	004
02	ROD H, CONNECTING 13208-300-000	004
03	BOLT, CONNECTING ROD 13213-333-003	008
04	NUT, CONNECTING ROD 13214-300-000	008
05	BEARING A, CONN ROD 13215-300-013	008
05	BEARING B, CONN ROD 13215-413-015	008
05	BEARING B, CONN ROD 13216-300-013	008
05	BEARING C, CONN ROD 13216-413-015	008
05	BEARING D, CONN ROD 13217-413-015	008
05	BEARING D, CONN ROD 13217-413-015	008
05	BEARING D, CONN ROD 13218-300-013	008
05	BEARING E, CONN ROD 13218-413-015	008
06	BEARING A 13315-422-003	010
06	BEARING A 13315-422-003	010
06	BEARING A 13315-425-003	010
06	BRG B, CRANKSHAFT 13316-300-013	010
06	BRG B, CRANKSHAFT 13316-425-003	010
06	BRG B, CRANKSHAFT 13316-425-003	010
06	BRG C, CRANKSHAFT 13317-425-003	010
06	BRG C, CRANKSHAFT 13317-425-003	010

06	BRG C, CRANKSHAFT 13317-425-003	010
06	BRG D, CRANKSHAFT 13318-422-003	010
06	BRG D, CRANKSHAFT 13318-422-003	010
06	BRG D, CRANKSHAFT 13318-425-003	010
07	OIL SEAL (30X42X8) 91201-300-003	001

www.hondachopper.com