



NUMBER	PART NAME-HONDA# NAME-HONDA#	QTY NEEDED
01	CLUTCH (OUTER) 22100-300-020	001
02	CENTER, CLUTCH 22120-300-040	001
03	DISK A, CL FRICTION 22201-371-000	007
03	DISK A, CL FRICTION 22201-371-000	007
04	PLATE, CLUTCH 22321-MG8-000	006
04	PLATE, CLUTCH 22321-MG8-000	006
05	PLATE, CLU PRESS 22350-300-030	001
06	PLATE, CLUTCH LIFTER 22360-300-010	001
07	PIECE, CLUTCH LIFTER 22846-300-010	001
07	PIECE, CLUTCH LIFTER 22846-300-010	001
08	NUT, LOCK (16MM) 90231-200-010	001
08	NUT, LOCK (16MM) 90231-KCS-651	001
09	WASHER (16MM) 90431-292-000	001
10	WASHER (25MM) 90432-300-303	001
10	WASHER (25MM) 90432-300-303	001
11	WASHER (16MM) 90481-292-000	001
12	SPRING, CLUTCH 95014-75140	004
13	BOLT, FLANGE (6X20) 95701-06020-00	004
13	BOLT, FLANGE (6X20) 95701-06020-00	004
13	BOLT, FLANGE (6X20) 95701-06020-00	004
13	BOLT, FLANGE (6X20) 95701-06020-00	004
14	BEARING (6003) 96100-60030-00	001
14	BEARING (6003) 96100-60030-00	001