



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	ELEMENT, AIR CLEANER 17211-405-000	001
01	ELEMENT, AIR CLEANER 17211-405-000	001
01	ELEMENT, AIR CLEANER 17211-405-000	001
02	HOUSING, AIR CLEANER 17212-341-000	001
03	SEPARATOR *NH1* 17213-300-000B	001
04	STAY, R. A/CLNR HSG 17215-300-030	001
05	STAY, L. A/CLNR HSG 17216-300-030	001
06	PLATE, R. A/CLNR HSG 17217-300-330	001
07	PLATE, L. A/CLNR HSG 17218-300-330	001
08	RUBBER 17219-300-010	004
09	COLLAR 17220-300-010	006
10	GASKET, A/CLNR HSG 17221-341-000	001
11	COVER, AIR CLEANER 17231-341-010	001
12	TUBE 17253-341-300	004
13	BAND, A/CLNR TUBE 17255-230-000	004
14	BOLT 90143-300-020	002
15	BOLT, A/CLNR HSG 90144-300-020	002
16	NUT 90301-300-000	002

17	WASHER B 90554-240-000	002
18	WASHER (18MM) 90581-831-650	002
18	WASHER (18MM) 90581-831-650	002
19	O-RING (6MM) 91301-704-000	002
20	BOLT, HEX. (6X12) 92101-06012-0A	002
20	BOLT, HEX. (6X12) 92101-06012-0A	002
20	BOLT, HEX. (6X12) 92101-06012-0A	002
21	SCREW, PAN (4X20) 93500-04020-0A	004
22	SCREW, PAN (6X20) 93500-06020-0A	004
22	SCREW, PAN (6X20) 93500-06020-0A	004
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
23	NUT, HEX. (6MM) 94001-06200-0S	002
24	WASHER, PLAIN (6MM) 94101-06800	002
24	WASHER, PLAIN (6MM) 94101-06800	002
24	WASHER, PLAIN (6MM) 94101-06800	002
25	WASHER, SPRING (6MM) 94111-06000	002
26	PIN, SPLIT (2.0X15) 94201-20150	002