



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	GASKET 11397-300-306	001
01	GASKET 11397-300-306	001
01	GASKET 11397-300-306	001
01	GASKET 11397-300-306	001
02	COVER, ALTERNATOR 11631-300-040	001
03	GEAR 28101-300-000	001
04	SHAFT 28106-300-000	001
05	PLATE 28109-300-000	001
06	GEAR, STARTER CLUTCH 28110-300-000	001
07	CLUTCH, STARTER 28120-300-000	001
08	SPRING 28125-516-030	003
09	CAP 28126-516-020	003
10	PLATE 28128-516-000	001
11	ROTOR 31101-300-035	001

12	STATOR 31102-300-045	001
12	STATOR 31102-300-045	001
13	COIL, FIELD 31103-300-045	001
13	COIL, FIELD 31103-300-045	001
14	WIRE HARNESS, ALTNTR 31110-300-154	001
15	PLATE 32116-300-010	001
16	BOLT, ROTOR SET 90014-300-010	001
16	BOLT, ROTOR SET 90014-392-010	001
17	SCREW, FLAT (8X22) 90053-300-000	003
18	WASHER (11MM) 90425-300-000	003
19	WASHER (12MM) 90428-300-010	001
20	ROLLER (15X13) 91101-516-000	003
21	OIL SEAL (25X33X4) 91215-300-003	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
22	BOLT, HEX. (6X16) 92101-06016-0A	001
23	SCREW, PAN (6X20) 93500-06020-0A	003
23	SCREW, PAN (6X20) 93500-06020-0A	003
24	SCREW, PAN (6X28) 93500-06028-0A	004
24	SCREW, PAN (6X28) 93500-06028-0A	004
25	SCREW, PAN (6X32) 93500-06032-0A	007
25	SCREW, PAN (6X32) 93500-06032-0A	007
26	SCREW, PAN (6X35) 93500-06035-0A	001
26	SCREW, PAN (6X35) 93500-06035-0A	001
27	PIN, DOWEL (8X14) 94301-08140	001