



| NUMBER | PART NAME-HONDA# | QTY NEEDED |
|--------|---------------------------------------|------------|
| 01 | REGULATOR ASSY. 31400-300-035 | 001 |
| 02 | RUBBER 31403-323-000 | 002 |
| 02 | RUBBER 31403-323-000 | 002 |
| 03 | RECTIFIER, SILICON 31700-124-003 | 001 |
| 03 | RECTIFIER, SILICON 31700-124-008 | 001 |
| 04 | RECTIFIER ASSY. 31700-333-008 | 001 |
| 04 | RECTIFIER ASSY. 31700-333-008 | 001 |
| 05 | STAY, DIODE 31706-341-900 | 001 |
| 06 | BOX ASSY., FUSE 32110-341-702 | 001 |
| 07 | COVER, FUSE BOX 32117-341-702 | 001 |
| 08 | FUSE, GROMMET 32118-341-702 | 001 |
| 09 | CABLE 32401-341-000 | 001 |
| 10 | COVER 32412-MJ0-000 | 001 |
| 11 | COVER B 32413-300-010 | 001 |
| 12 | CABLE 32601-341-700 | 001 |
| 13 | SW, STARTER MAGNETIC 35850-371-670 | 001 |
| 14 | STAY 35851-392-000 | 001 |

| | | |
|----|---------------------------------------|-----|
| 15 | RELAY, TURN SIGNAL 38301-KJ6-743 | 001 |
| 15 | RELAY, TURN SIGNAL 38301-KJ6-743 | 001 |
| 15 | RELAY, TURN SIGNAL 38301-KJ6-743 | 001 |
| 15 | RELAY, TURN SIGNAL 38301-KJ6-743 | 001 |
| 16 | SUSPENSION 38306-292-670 | 001 |
| 17 | BAND F, BATTERY 95012-17001 | 001 |
| 17 | BAND F, BATTERY 95012-17001 | 001 |
| 18 | RUBBER A, BATTERY 50323-300-010 | 004 |
| 19 | COLLAR, BATTERY BOX 50324-300-000 | 004 |
| 20 | BOX, BATTERY 50325-341-701 | 001 |
| 21 | TUBE ASSY., BATTERY 50326-341-670 | 001 |
| 22 | RUBBER B, BATTERY 50327-300-000 | 004 |
| 23 | RUBBER C, BATTERY 50329-300-010 | 001 |
| 24 | PLATE, ELECTRIC BASE 50330-341-000 | 001 |
| 25 | COLLAR 84706-286-000 | 002 |
| 26 | WASHER, PLAIN (6MM) 94103-06800 | 004 |
| 26 | WASHER, PLAIN (6MM) 94103-06800 | 004 |
| 27 | WASHER (18MM) 90581-831-650 | 002 |
| 27 | WASHER (18MM) 90581-831-650 | 002 |
| 28 | BOLT, HEX. (5X14) 92101-05014-0A | 002 |
| 28 | BOLT, HEX. (5X14) 92101-05014-0A | 002 |
| 29 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 29 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 29 | BOLT, HEX. (6X12) 92101-06012-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 30 | BOLT, HEX. (6X16) 92101-06016-0A | 002 |
| 31 | BOLT, HEX. (6X20) 92101-06020-0A | 002 |
| 31 | BOLT, HEX. (6X20) 92101-06020-0A | 002 |

| | | |
|----|-------------------------------------|-----|
| 32 | BOLT, HEX. (6X25) 92101-06025-0A | 004 |
| 32 | BOLT, HEX. (6X25) 92101-06025-0A | 004 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 33 | NUT, HEX. (6MM) 94001-06200-0S | 001 |
| 34 | NUT, HEX. (8MM) 94001-08000-0S | 001 |
| 35 | NUT, HEX. (6MM) 94002-06080-0S | 002 |
| 35 | NUT, HEX. (6MM) 94002-06080-0S | 002 |
| 35 | NUT, HEX. (6MM) 94002-06080-0S | 002 |
| 35 | NUT, HEX. (6MM) 94002-06080-0S | 002 |
| 36 | WASHER, PLAIN (5MM) 94101-05000 | 002 |
| 37 | WASHER, PLAIN (6MM) 94101-06800 | 004 |
| 37 | WASHER, PLAIN (6MM) 94101-06800 | 004 |
| 37 | WASHER, PLAIN (6MM) 94101-06800 | 004 |
| 38 | WASHER, SPRING (6MM) 94111-06000 | 001 |
| 39 | WASHER, SPRING (6MM) 94111-06800 | 002 |
| 40 | WASHER, SPRING (8MM) 94111-08000 | 001 |
| 41 | FUSE A (5A) 98200-10500 | 002 |
| 42 | FUSE (7A) 98200-10700 | 002 |
| 43 | FUSE (15A) 98200-11500 | 002 |
| 44 | BATTERY ASSY. 31500-425-672AH | 001 |
| 44 | BATTERY ASSY. 31500-425-672AH | 001 |