



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	CLUTCH (OUTER) 22100-392-000	001
01	CLUTCH (OUTER) 22100-392-010	001
02	CENTER, CLUTCH 22120-300-040	001
02	CENTER, CLUTCH 22120-300-050	001
03	DISK A, CL FRICTION 22201-371-000	006
03	DISK A, CL FRICTION 22201-371-000	006
04	DISK B, CL FRICTION 22202-392-000	001
05	PLATE, CLUTCH 22321-MG8-000	005
05	PLATE, CLUTCH 22321-MG8-000	006
05	PLATE, CLUTCH 22321-MG8-000	006
05	PLATE, CLUTCH 22321-MG8-000	005
06	PLATE B, CLUTCH 22322-371-020	001
07	PLATE, CLU PRESS 22350-300-030	001
08	PLATE, CLUTCH LIFTER 22360-300-010	001
09	SPRING, CLUTCH 22401-323-003	004
09	SPRING, CLUTCH 22401-323-003	004

09	SPRING, CLUTCH 22401-323-003	004
10	PIECE, CLUTCH LIFTER 22846-300-010	001
10	PIECE, CLUTCH LIFTER 22846-300-010	001
11	NUT, LOCK (16MM) 90231-200-010	001
11	NUT, LOCK (16MM) 90231-KCS-651	001
12	WASHER (16MM) 90431-292-000	001
13	WASHER (25MM) 90432-392-000	001
14	WASHER (16MM) 90481-292-000	001
15	CIRCLIP (40MM) 90602-371-000	001
16	BOLT, FLANGE (6X22) 95701-06022-00	004
16	BOLT, FLANGE (6X22) 95701-06022-00	004
17	BEARING (6003) 96100-60030-00	001
17	BEARING (6003) 96100-60030-00	001

[www.hondachopper.com](http://www.hondachopper.com)