



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	GUIDE, VALVE 12025-300-300	004
02	GUIDE, EX. VALVE 12027-300-330	004
03	RUBBER, INSERT 12620-286-000	002
03	RUBBER, INSERT 12620-286-000	002
04	CYLINDER HEAD 12200-300-405	001
05	CLIP, VALVE GUIDE 12211-250-310	008
06	ORIFICE, OIL CONTROL 12238-300-010	002
07	GASKET, CYL HD 12251-300-306	001
07	GASKET, CYL HD 12251-300-306	001
07	GASKET, CYL HD 12251-300-306	001
08	INSULATOR A, CARB 16211-300-030	002
09	INSULATOR B, CARB 16212-300-030	002
10	BAND, INSULATOR 16223-KS5-000	008
10	BAND, INSULATOR 16223-KS5-000	008

11	FLANGE, EX. PIPE 18236-300-030	004
12	GASKET, EX. PIPE 18291-MM5-860	004
12	GASKET, EX. PIPE 18291-MM5-860	004
13	BOLT, FLANGE (6X35) 95701-06035-00	004
13	BOLT, FLANGE (6X35) 95701-06035-00	004
13	BOLT, FLANGE (6X35) 95701-06035-00	004
13	BOLT, FLANGE (6X35) 95701-06035-00	005
13	BOLT, FLANGE (6X35) 95701-06035-00	004
13	BOLT, FLANGE (6X35) 95701-06035-00	004
13	BOLT, FLANGE (6X35) 95701-06035-00	005
14	BOLT, STUD (6X58) 90055-300-000	004
15	NUT, FLANGE (8MM) 94050-08000	016
15	NUT, FLANGE (8MM) 94050-08000	016
16	WASHER (14MM) 90485-035-000	016
17	O-RING (5.8X1.9) 91305-323-000	004
17	O-RING (5.6X1.9) 91318-ME5-003	004
18	RUBBER, SEALING 91318-300-013	006
19	SCREW, PAN (4X22) 93500-04022-0A	008
20	SCREW, FLAT (8X22) 93600-08022	008
21	PIN, DOWEL (8X14) 94301-08140	006
22	BOLT, FLANGE (6X35) 95701-06035-00	001
22	BOLT, FLANGE (6X35) 95701-06035-00	001
23	BOLT, FLANGE (6X90) 95701-06090-00	001
23	BOLT, FLANGE (6X90) 95701-06090-00	001
24	SPARK PLUG (D8EA) 98069-58717	004
24	SPARK PLUG (D8EA) 98069-58717	004
24	SPARK PLUG (D8EA) 98069-58717	004
24	SPARK PLUG (D8EA) 98069-58717	004
24	SPARK PLUG (D8EA) 98069-58717	004

24	SPARK PLUG (D8EA) 98069-58717	004
24	SPARK PLUG (D8EA) 98069-58717	004

www.hondachopper.com