



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	BODY ASSY., OIL 15010-300-000	001
02	PUMP ASSY., OIL 15100-300-000	001
03	BASE, OIL PUMP 15105-300-010	001
04	GASKET, OIL PUMP 15135-300-010	001
05	VALVE, RELIEF 15140-300-010	001
06	SPRING, RELIEF VALVE 15145-300-000	001
07	CAP 15147-300-000	001
08	SCREEN, OIL STRAINER 15150-300-000	001
09	COLLAR, O-RING 15155-300-000	003
10	VALVE 15161-300-000	001
11	OIL SEAL 15166-300-000	001
12	SPRING 15171-300-010	001
13	CAP 15176-300-000	001
14	O-RING (15X2.5) 91302-377-000	004

14	O-RING (15X2.5) 91302-377-000	004
15	SCREW, PAN (6X20) 93500-06020-0A	002
15	SCREW, PAN (6X20) 93500-06020-0A	002
16	SCREW, PAN (6X32) 93500-06032-0A	004
16	SCREW, PAN (6X32) 93500-06032-0A	004
17	PIN, DOWEL (4X8) 94302-04080	002
18	BOLT, FLANGE (6X35) 95701-06035-00	003
18	BOLT, FLANGE (6X35) 95701-06035-00	003
18	BOLT, FLANGE (6X35) 95701-06035-00	003

www.hondachopper.com