



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	RING (66.5MM) 13491-300-000	001
02	RING B 13496-300-000	001
03	TENSIONER 13620-300-010	001
04	SPROCKET 23110-392-000	001
05	CHAIN, PRIMARY (68L) 23131-300-315	002
05	CHAIN, PRIMARY (68L) 23131-300-315	002
07	GEAR (56T) 23511-300-020	001
08	SHAFT, FINAL DRIVEN 23521-392-000	001
09	SPROCKET (18T) 23801-300-620	001
10	PLATE 23811-292-000	001
11	GEAR, KICK STARTER 28210-300-000	001
12	SPINDLE 28250-300-020	001
13	FLANGE, KICK STARTER 28271-393-000	001
13	FLANGE, KICK STARTER 28271-393-000	001
14	PAWL, KICK STARTER 28252-300-020	001
15	SPRING 28253-300-000	001
16	PIN, KICK STOPPER 28254-300-000	001
17	PIN (4X37) 28255-300-000	001
18	PIN (6X35) 28256-300-000	001
19	SPRING 28261-300-010	001

20	BEARING (6008) 91004-300-000	001
21	BEARING (6205) 96100-62050-00	001
21	BEARING (6205) 96100-62050-00	001
21	BEARING (6205) 96100-62050-00	001
21	BEARING (6205) 96100-62050-10	001
22	BEARING (5206) 91012-MG7-003	001
22	BEARING (5206) 91012-MG7-003	001
23	BEARING (25X32X20) 91010-300-008	002
24	OIL SEAL (25X62X7) 91205-300-005	001
25	BOLT, HEX. (6X12) 92101-06012-0A	002
25	BOLT, HEX. (6X12) 92101-06012-0A	002
25	BOLT, HEX. (6X12) 92101-06012-0A	002
26	BOLT, HEX. (6X16) 92101-06016-0A	001
26	BOLT, HEX. (6X16) 92101-06016-0A	001
26	BOLT, HEX. (6X16) 92101-06016-0A	001
26	BOLT, HEX. (6X16) 92101-06016-0A	001
26	BOLT, HEX. (6X16) 92101-06016-0A	001
26	BOLT, HEX. (6X16) 92101-06016-0A	001