



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	COVER, L. RR. 11351-300-060	001
02	RUBBER 11354-300-010	001
03	COVER, CR/CASE TRANS 11360-300-050	001
04	GASKET, TRANS CVR 11395-300-306	001
04	GASKET, TRANS CVR 11395-300-306	001
05	STARTER MOTOR ASSY. 31200-300-030	001
06	BRUSH SET, CARBON 31201-292-158	001
07	SPRING, CARBON BRUSH 31204-292-158	002
08	BOLT, SETTING 31205-286-158	002
09	O-RING (60X1.4) 31206-402-008	001
09	O-RING (60X1.4) 31206-402-008	001
10	WIRE ASSY. 31270-300-154	001
11	COVER, STARTER MOTOR 31280-300-000	001
12	GSKT, START MTR CVR 31282-300-020	001
13	GROM, O/PRESS SW WR 31283-300-000	001

14	SWITCH, OIL PRESSURE 37240-P13-013	001
14	SWITCH, OIL PRESSURE 37240-P13-013	001
14	SWITCH, OIL PRESSURE 37240-P13-013	001
14	SWITCH, OIL PRESSURE 37240-P13-013	001
15	OIL SEAL (14X28X7) 91206-286-013	001
15	OIL SEAL (14X28X7) 91206-286-013	001
16	O-RING (24.4X3.1) 91312-MG7-003	001
16	O-RING (24.4X3.1) 91312-MG7-003	001
16	O-RING (24.4X3.1) 91312-MG7-003	001
17	BOLT, HEX. (6X12) 92101-06012-0B	002
17	BOLT, HEX. (6X12) 92101-06012-0B	002
18	SCREW, PAN (6X32) 93500-06032-0A	002
18	SCREW, PAN (6X32) 93500-06032-0A	002
19	SCREW, PAN (6X35) 93500-06035-0A	002
19	SCREW, PAN (6X35) 93500-06035-0A	002
20	SCREW, PAN (6X40) 93500-06040-0A	003
20	SCREW, PAN (6X40) 93500-06040-0A	003
21	SCREW, PAN (6X50) 93500-06050-0A	002
21	SCREW, PAN (6X50) 93500-06050-0A	002
22	SCREW, PAN (6X55) 93500-06055-0A	002
22	SCREW, PAN (6X55) 93500-06055-0A	002
23	WASHER, PLAIN (6MM) 94101-06200	002
24	PIN, DOWEL (8X14) 94301-08140	002
25	BOLT, FLANGE (6X56) 95700-06056-00	002