



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	SPROCKET (48T) 41201-300-870	001
02	PLATE, SPROCKET SIDE 41211-341-000	001
03	RETAINER, RR. 41231-283-000	001
04	RETAINER, RR. 41231-300-020	001
05	DAMPER, R. RR. WHEEL 41241-300-040	004
06	DAMPER, RR. WHEEL 41241-300-050	004
07	DAMPER, L. RR. WHEEL 41242-300-020	004
08	AXLE, RR. WHEEL 42301-300-020	001
08	AXLE, RR. WHEEL 42301-300-020	001
09	COLR, RR. WHEEL SIDE 42311-300-010	001
10	HUB, RR. WHEEL 42601-300-050	001
10	HUB, RR. WHEEL 42601-300-050	001
10	HUB, RR. WHEEL 42601-300-050	001
11	SLEEVE, RR. AXLE 42605-300-000	001
12	SPOKE A, RR. 42606-300-003	020
12	SPOKE A, RR. 42606-341-000	020
12	SPOKE (8X142.5) 97313-69125-R0	020
12	SPOKE (8X142.5) 97313-69125-R0	020
13	SPOKE B, RR. 42607-341-000	020
13	SPOKE B, RR. 42607-341-000	020

[illegible]

29	BEARING (6304Z) 96120-63040-10	002
29	BEARING (6304Z) 96120-63040-10	002
30	BEARING (6305Z) 96120-63050	001

www.hondachopper.com