



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	PEDAL, GEARSHIFT 24701-405-000	001
02	RUBBER, CHANGE PEDAL 24781-371-000	001
03	ARM, KICK STARTER 28240-392-000	001
04	SPRING, KICK STARTER 28292-250-010	001
05	CLIP 28293-250-000	001
06	RUBBER, KICK STARTER 28311-329-000	001
07	PIN 28321-300-000	001
08	SPRING 28333-300-000	001
09	SWITCH ASSY., STOP 35350-086-721	001
10	SPRING, STOP SWITCH 35357-393-000	001
11	ROD, RR. BRAKE 43450-405-000	001
12	PEDAL, RR. BRAKE 46500-405-010	001
13	SPINDLE, RR. BRAKE 46510-405-010	001
14	SPRING, BRAKE PEDAL 46514-405-000	001
15	BRACKET, STOP SWITCH 50146-392-000	001
16	BOLT, HEX. (6X20) 92101-06020-0A	001
16	BOLT, HEX. (6X20) 92101-06020-0A	001
17	BOLT, HEX. (8X28) 92101-08028-0B	001

18	BOLT-WASHER (8X28) 93482-08028-00	001
19	WASHER, PLAIN (8MM) 94101-08000	001
20	PIN, COTTER (1.6X25) 94201-16250	001
20	PIN, COTTER (1.6X25) 94201-16250	001
21	SPRING A, BRAKE ROD 95014-73100	001
21	SPRING A, BRAKE ROD 95014-73100	001
22	JOINT B, BRAKE ARM 95015-32001	001
23	NUT B 95015-42000	001
24	PIN B 95015-52000	001
25	BALL (#8) (1/4) 96211-08000	001

[www.hondachopper.com](http://www.hondachopper.com)