



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	ADJUSTER 40543-392-000	001
01	ADJUSTER 40543-392-000	001
02	SPROCKET (41T) 41201-405-000	001
03	PLATE, SPROCKET SIDE 41211-405-000	001
04	RETAINER, RR. 41231-283-000	001
05	RETAINER, RR. 41231-300-020	001
06	DAMPER, RR. WHEEL 41241-300-050	004
07	AXLE, RR. WHEEL 42301-425-870	001
07	AXLE, RR. WHEEL 42301-425-870	001
08	COLR, RR. WHEEL SIDE 42311-425-870	001
08	COLR, RR. WHEEL SIDE 42311-425-870	001
09	HUB, RR. WHEEL 42601-300-050	001
09	HUB, RR. WHEEL 42601-300-050	001
10	SLEEVE, RR. AXLE 42605-393-000	001
11	FLANGE, FINAL DRIVEN 42610-405-000	001
12	COLLAR, RR. DISTANCE 42620-ME1-405	001
12	COLLAR, RR. DISTANCE 42620-ME1-405	001
13	RIM, RR. WHEEL 42701-425-771	001
13	RIM, RR. WHEEL 42701-425-771	001
13	RIM, RR. WHEEL 42701-425-771	001

14	TIRE (4.50H17) (4PR) 42711-MA4-671	001
14	TIRE (4.50H17) (4PR) 42711-MA4-671	001
14	TIRE (4.50H17) (4PR) 42711-MA4-671	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
15	TUBE, TIRE (5.10-17) 42712-MA0-005	001
16	FLAP, TIRE (17) 42713-371-000	001
17	BALANCER (20G) 44606-283-000	AR
17	BALANCER (15G) 44607-283-000	AR
17	BALANCER (10G) 44608-283-000	AR
17	BALANCER, WHEEL (5G) 44609-283-000	AR
18	BOLT, CHAIN ADJ. 90119-300-000	001
19	BOLT, STUD (12X54) 90128-341-000	004
20	OIL SEAL (34X55X9) 90753-283-000	001
21	O-RING (68X2.6) 91258-300-013	001
22	NUT, HEX. (8MM) 94002-08000-0S	001
23	NUT, HEX. (12MM) 94030-12000	004
24	WASHER A7, TONGUED 94108-17000	002
25	BEARING (6304U) 96140-63040-10	002
26	BEARING (6305U) 96140-63050-10	001
27	SPOKE BS (8X128) 97371-69094-R0	020
27	SPOKE BS (8X128) 97371-69094-R0	020
28	SPOKE BS (8X127.5) 97C31-69091-R0	020
28	SPOKE BS (8X127.5) 97C31-69091-R0	020