



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	STAND, MAIN 50500-405-000	001
02	PLATE 50523-300-010	001
03	PIPE 50526-300-000	001
05	BAR, SIDE STAND 50540-405-010	001
05	BAR, SIDE STAND 50540-405-010	001
07	RUBBER, STAND 50548-356-700	001
08	COLLAR 50549-356-700	001
09	PIN, STEP BAR JOINT 50603-033-010	002
09	PIN, STEP BAR JOINT 50603-033-010	002
10	BAR, R. STEP 50615-405-000	001
11	SPRING, R. 50617-300-670	001
11	SPRING, R. 50617-300-670	001
12	SLIDER, FOOTPEG 50618-431-670	002
12	SLIDER, FOOTPEG 50618-431-670	002
13	STOPPER, STEP RUBBER 50619-MB9-000	002
14	STEP ASSY., R. 50630-405-000	001
15	ARM, R. STEP 50632-405-000	001
16	STEP ASSY., L. 50640-405-000	001
17	BAR, L. *NH1* 50641-300-670B	001

18	ARM, L. STEP 50642-405-000	001
19	SPRING, L. 50644-300-670	001
20	RUBBER, STEP 50661-405-000	002
21	COLLAR 84706-286-000	002
22	SCREW 90108-283-000	001
24	GUIDE, BREATHER 90514-405-000	001
25	BOLT, HEX. (6X25) 92025-06025-0A	001
25	BOLT, HEX. (6X25) 92025-06025-0A	001
26	BOLT-WASHER (6X28) 93401-06028-00	001
26	BOLT-WASHER (6X28) 93401-06028-00	001
27	NUT, HEX. (6MM) 94002-06000-0S	001
27	NUT, HEX. (6MM) 94002-06000-0S	001
28	NUT, HEX. (10MM) 94030-10200	001
29	WASHER, PLAIN (8MM) 94101-08000	002
30	PIN, COTTER (1.6X25) 94201-16250	002
30	PIN, COTTER (1.6X25) 94201-16250	002
31	PIN, SPLIT (2.5X30) 94201-25300	001
33	SPRING G, MAIN STAND 95014-71702	001
35	SPRING D, SIDE STAND 95014-72402	001
36	BOLT, FLANGE (6X18) 95701-06018-00	002
36	BOLT, FLANGE (6X18) 95701-06018-00	002