



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	RING A 13495-300-000	002
02	HOLDER 23150-300-010	001
03	MAINSHAFT (18T) 23210-392-000	001
04	COUNTERSHAFT, TRANS 23220-371-000	001
05	GEAR (45T) 23421-300-050	001
06	BUSH, SPLINE (29MM) 23425-392-000	001
07	GEAR (24T & 27T) 23431-392-000	001
08	GEAR SET 23440-410-305	001
08	GEAR SET 23440-410-305	001
09	GEAR SET 23440-410-305	001
10	GEAR (41T) 23441-410-000	001
11	GEAR (30T) 23450-392-000	001
12	GEAR ASSY. (36T) 23460-410-305	001
12	GEAR ASSY. (36T) 23460-410-305	001

13	GEAR ASSY. (36T) 23460-410-305	001
14	GEAR (36T) 23461-410-000	001
15	GEAR (34T) 23471-300-010	001
16	GEAR (33T) 23481-300-020	001
17	BUSH, SPLINE (28MM) 23485-392-000	001
18	BUSH (28MM) 23485-410-003	002
18	BUSH (28MM) 23485-410-003	002
19	GEAR (32T) 23491-392-000	001
20	GEAR (43T) 23501-392-000	001
21	WASHER (25MM) 90451-MB2-000	001
21	WASHER (25MM) 90451-MB2-000	003
21	WASHER (25MM) 90451-MB2-000	001
21	WASHER (25MM) 90451-MB2-000	003
22	WASHER (25X34) 90452-371-000	002
23	WASHER (20MM) 90458-292-000	001
24	WASHER A (25MM) 90458-506-810	001
25	CIRCLIP (25MM) 90601-300-000	005
26	PLUG (10X10) 90809-300-300	001
27	BEARING (6304) 96100-63040-00	001
27	BEARING (6304) 96100-63040-00	001
27	BEARING (6304) 96100-63040-00	001
28	BEARING (6205) 91002-300-008	001
28	BEARING (6205) 91002-300-008	001
29	BEARING (6304HS) 91003-235-000	001
30	O-RING (4.9X2.5) 91301-426-010	001
30	O-RING (4.9X2.5) 91301-426-010	001
30	O-RING (4.9X2.5) 91301-426-010	001
31	SCREW, FLAT (6X20) 93600-06020-0A	004
31	SCREW, FLAT (6X20) 93600-06020-0A	004

32	BEARING (6204) 96100-62040-00	001
32	BEARING (6204) 96100-62040-00	001

www.hondachopper.com