



NUMBER	PART NAME-HONDA#	QTY NEEDED
01	SEAL, VALVE STEM 12209-MB9-003	008
01	SEAL, VALVE STEM 12209-MB9-003	008
02	ARM A, VALVE ROCKER 14431-300-030	004
03	ARM B, VALVE ROCKER 14432-300-030	004
04	SHAFT 14461-300-020	002
05	SHAFT 14462-300-010	002
06	VALVE, IN. 14711-300-015	004
07	VALVE, EX. 14721-300-015	004
08	SPRING, VALVE 14751-300-003	008
09	SPRING, VALVE 14761-300-003	008
10	RETAINER, VLV SPR 14771-410-010	008
11	SEAT, VALVE SPRING 14775-410-010	008
11	SEAT, VALVE SPRING 14775-410-010	008
12	COTTER, VALVE 14781-410-000	016
13	SCREW, TAPPET ADJ 90012-426-000	008
13	SCREW, TAPPET ADJ 90012-426-000	008
14	NUT, TAPPET ADJ 90206-250-000	008
14	NUT, TAPPET ADJ 90206-250-000	008